Using the remote control

Turn on the stove

Press and hold the ignition button on the remote control for 3 seconds until the message "Check-up" appears on the display.

Turning off the stove

Press and hold the ignition button on the remote control for 3 seconds until the message "Final cleaning" appears on the display.

Changing the temperature

1. Wake up the remote control by briefly pressing the ignition button
2. Press the button
3. Set the desired temperature using the arrows
4. When the desired temperature is selected, confirm by pressing the Set button

Change the power level

The power corresponds to the quantity of pellets fed into the fire. It can be set from 1 (few pellets) to 5 (many). It will have an impact on how quickly the unit heats up and on the size of the flame.

1. Wake up the remote control by briefly pressing the ignition button
2. Press the button
3. Set the desired wattage using the arrows
4. When the desired power is selected, confirm by pressing the Set button

Change the ventilation

On the "Soft" or "Multi-air" models, it is possible to choose the speed of the air fan in the room as well as the speed of the ducted fans.

The power ranges from 1 to 5 on "Multi-air" models and from 0 (off) to 5 on "Soft" models. Speed "A" corresponds to the automatic mode: the stove will define according to the room temperature and the set temperature which speed is the most suitable.

1. Wake up the remote control by briefly pressing the ignition button
2. Press the Esc button
3. Set the desired speed by means of the arrow
4. When the desired speed is selected, confirm by pressing the Set button

Activate the Stand-By

If the "Stand-By" mode is activated, the stove will turn off when it has reached the desired temperature. If it

is not activated, the stove will never turn off and will only reduce its power.

1. Wake up the remote control by briefly pressing the ignition button
2. Press the Set button
3. Select the first option in the menu bar (01. STAND-BY). Press the Set button again to confirm
4. Press the up arrow button . A "seen" logo will appear
5. Press the Set button to confirm the mode
6. Finally, return to the main menu by pressing the power button

Using the remote control